

Manual, Assembly instruction: Brodit 853494

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place the ProClip in the same position as shown in the pictures. This ProClip consists of two parts. Part 1: Attaching part. Part 2: ProClip face plate.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the gearshift and the console, to widen the gap. Peel off the cover of the adhesive tape on Part 1. Press the angled edge on Part 1 into the gap next to the gap opener. Pull out the gap opener.

2. Open up the predrilled holes in part 2 with a screwdriver (Philips). Peel off the cover of the adhesive tape on Part 2. Place Part 2 onto Part 1 so the holes match and the adhesive is to the left. Screw Part 2 onto Part 1 with the enclosed screws.

3. The ProClip is to be in the exact same position as shown in the picture.

4. The ProClip is in place.