

Manual, Assembly instruction: Brodit 853496

Angled mount NOT for wood grain panel.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the grooved edge of the ProClip into the gap between the frame surrounding the control panel and the dashboard.
2. Press the right side of the ProClip towards the dashboard so the adhesive tape attaches.
3. Press forwards on the ProClip so the adhesive tape attaches.
4. The ProClip is in place.