

Manual, Assembly instruction: Brodit 853498

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the angled edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.
3. Press the angled edge of the ProClip into the gap between the dashboard and the hatch.
4. The ProClip is in place.