

Manual, Assembly instruction: Brodit 853500

Center mount, Left

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Press the grooved edge on the lower part of the ProClip into the gap above the gap opener. Press until you hear/feel it snaps into the gap. Pull out the gap opener.
2. Press forwards on the upper part of the ProClip so the grooved edge snaps into the gap between the frame surrounding the air vent and the dashboard. Press until you hear/feel it snaps into the gap.
3. Press forwards on the ProClip so it goes all the way into the gaps.
4. The ProClip is in place.