

Manual, Assembly instruction: Brodit 853505

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap.

2. Press the grooved edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener. Press forwards on the ProClip until you hear/feel it snaps into place.

3. Press the grooved edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the frame surrounding the control panel. Press forwards on the ProClip until you hear/feel it snaps into place.

4. The ProClip is in place.