

Manual, Assembly instruction: Brodit 853506

Angled mount ONLY Classic



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap between the control panel and the surrounding frame, to widen the gap. Place the gap openers about 10 cm apart. Peel off the adhesive tape covers on the ProClip.

2. Press the grooved edge of the ProClip into the gap between the gap openers. Pull out the gap openers. Press forwards on the ProClip until you hear/feel it snaps into place and the adhesive tapes attach.

3. The ProClip is in place.

4. The ProClip is in place.