

Manual, Assembly instruction: Brodit 853508

Angled mount, High

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Place the grooved edge of the ProClip into the gap below the gap opener.

2. Press forwards on the lower part of the ProClip.

3. Press forwards on the upper part of the ProClip. Press until you hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.