

Manual, Assembly instruction: Brodit 853522

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console frame and the dashboard sidewall, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press/hook the angled edge on the right side of the ProClip into the gap below the gap opener.
3. Place your fingers on the right side of the ProClip and press the ProClip towards the climate control panel so the curved edge goes into the gap between the climate control panel and the surrounding panel frame. Press forward on the left side of the ProClip to make sure the curved edge has hooked around the panel frame surrounding the climate control panel. Pull out the gap opener.
4. The ProClip is in place.