

## Manual, Assembly instruction: Brodit 853526

Angled mount ONLY for Ambiente 05-13, Classic 05-13, Elegance 05-13, RS 05-13, Scout 07-13.

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the right side of the ProClip into the gap between the frame surrounding the control panel and the dashboard.
2. Flip the ProClip leftwards, towards the steering wheel, so the curved right edge hooks behind the dashboard.
3. Press the grooved edge on the left part of the ProClip into the gap between the control panel and the surrounding frame. Press until you hear/feel it snaps into place.
4. The ProClip is in place.