

Manual, Assembly instruction: Brodit 853528

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the grooved edge of the ProClip into the gap between the control panel and the dashboard.
2. Press forwards on the ProClip until you hear/feel it snaps into the gap and the adhesive tapes attach.
3. Press on the ProClip so it is properly in place.
4. The ProClip is in place.