

Manual, Assembly instruction: Brodit 853529

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the grooved edge of the ProClip into the gap below the gap opener.
3. Press forwards on the ProClip until you hear/feel it snaps into the gap and the adhesive tapes attach. Pull out the gap opener.
4. The ProClip is in place.