

Manual, Assembly instruction: Brodit 853530

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip

1. Peel off the adhesive tape covers on the ProClip. Press the lower part of the ProClip into the gap below the frame surrounding the air vent.
2. Hook the angled edge on the upper part of the ProClip into the gap above the frame surrounding the air vent.
3. Hook downwards on the the upper part of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.