

Manual, Assembly instruction: Brodit 853539

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the curved edge against the gap between the center console panel frame and the air vent panel frame.
2. Press the curved edge into the gap and at the same time flip the ProClip upwards, towards the top of the air vent frame.
3. Use both hands, grip around the ProClip and push the upper part of the ProClip upwards and hook the angled edge over the air vent panel frame.
4. The ProClip is in place.