

Manual, Assembly instruction: Brodit 853540

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the curved edge on the right part of the ProClip into the gap in the center console sidewall.

2. Flip the ProClip towards the center console edge so the curved edge on the ProClip hooks into the gap.

3. Place your fingers behind the face plate and pull it toward you. While pulling the ProClip towards you, hook the angled edge on the left side of the ProClip over the console edge and press it into the gap between the center console panel frame and the console edge.

4. The ProClip is in place.