

Manual, Assembly instruction: Brodit 853541

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. Note: This mount can also be attached over the right air vent or you can have two attached at the same time.

1. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the upper part of the ProClip over the panel frame surrounding the air vent.
2. Pull the lower part of the ProClip towards you and place the grooved edge against the gap between the air vent panel frame and the climate control panel frame.
3. Press firmly forward on the lower part of the ProClip so the grooved edge goes into the gap. Press until you see or hear + feel it snaps into place.
4. The ProClip is in place.