

Manual, Assembly instruction: Brodit 853547

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap in the console sidewall, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the curved edge on the left part of the ProClip into the gap in the two panel sections.

3. Flip the right side of the ProClip rightwards so the curved right edge hooks behind the panel. Press firmly forward on the right side of the ProClip so the angled edge snaps into the gap above the gap opener. Pull out the gap opener

4. The ProClip is in place.