

Manual, Assembly instruction: Brodit 853551

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the grooved edge on left side of the ProClip over the left edge of the air vent housing.

2. Place your fingers on the right side of the ProClip and press towards the left side so the grooved right edge goes into the air vent and hooks around air vent panel frame edge.

3. The ProClip is in place.

4. The ProClip is in place.