

Manual, Assembly instruction: Brodit 853554

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the enclosed gap openers into the gap between the center console panel frame and the padded console edge, to widen the gap. Place the gap openers about 10 cm apart. Peel off the adhesive tape cover on the ProClip.

2. Press the grooved edge into the gap between the gap openers. Start by pressing in the upper part of the grooved edge. Continue by pressing in the lower part of the grooved edge. Pull out the gap openers.

3. Finally, press firmly forward on the mid part of the ProClip and at the same time; press/bend the ProClip against the padded console edge so the grooved edge clicks into place. Press until you see or hear/feel it snaps into place.

4. The ProClip is in place.