

Manual, Assembly instruction: Brodit 853559

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the center console panel frame and the dashboard, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the thin end with adhesive tape on the lower part of the ProClip into the gap between the stereo and the center console panel frame.
3. Press firmly forward on the upper part of the ProClip so the angled edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Press down on top of the ProClip to make sure the angled edge is all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.