

Manual, Assembly instruction: Brodit 853567

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard ledge, to widen the gap.
2. Press the lower part of the ProClip into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.
3. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard. Press the grooved edge on the upper part of the ProClip into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.