

Manual, Assembly instruction: Brodit 853568

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip. NOTE! It is important to place the ProClip in the exactly same position as shown in the pictures.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the surrounding frame, to widen the gap. Align the gap opener with the gap in the control panel, as shown in the picture. Peel off the adhesive tape covers on the ProClip.

2. Place the ProClip above the gap opener. Press the lower corner of the grooved part of the ProClip into the gap above the gap opener.

3. Press forwards on the lower part of the ProClip, in the same time continue by pressing forwards on the upper part of the ProClip so the grooved edge goes all the way into the gap. Press until you hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.