

Manual, Assembly instruction: Brodit 853572

Center mount NOT for wood grain panel.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thick ends of the enclosed gap openers into the gap between the frame surrounding the control panel and the dashboard, to widen the gap. Place the gap openers about 10 cm apart. Peel off the adhesive tape covers on the ProClip.

2. Press the angled edge on the right part of the ProClip into the gap between the control panel and the surrounding frame.

3. Press forwards on the left side of the ProClip so the angled left edge hooks into the gap between the gap openers. Press until you hear/fell it snaps into place. Pull out the gap openers.

4. The ProClip is in place.