

Manual, Assembly instruction: Brodit 853573

Angled mount NOT for wood grain panel.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Open the glove compartment. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the left part of the ProClip into the gap between the control panel and the dashboard.
2. Press forwards on the right side of the ProClip so the angled right edge hooks into the gap between the dashboard and the glove compartment.
3. Press the right end of the ProClip forwards/towards the center console side wall so the angled edge goes all the way into the gap. Press until you hear/feel it snaps into place.
4. The ProClip is in place.