

Manual, Assembly instruction: Brodit 853575

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Clean the surface on the control panel and the dashboard with the enclosed alcohol pad, where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Peel off the cover of the adhesive tape on Part 1. Press the angled edge on Part 1 into the gap below the gap opener.

2. Press Part 1 to the right, away from the steering wheel, so the angled edge hooks behind the control panel and the adhesive tape attaches to the dashboard. Pull out the gap opener.

3. Open up the predrilled holes in Part 2 with a screwdriver. Peel off the cover of the adhesive tape on part 2. Place Part 2 onto Part 1 so the holes match and the adhesive tape is on the left. Screw Part 2 onto Part 1 with the enclosed screws. Screw straight into Part 1, in the same angle as Part 1.

4. The ProClip is in place.