

Manual, Assembly instruction: Brodit 853580

Angled mount, Low



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Place the left part of the ProClip at the inside of the center console frame.
2. Pull the ProClip rightwards, in the same time press forwards on the right side of the ProClip so the right edge hooks behind the center console frame.
3. Press the ends of the ProClip towards the center console frame, on both sides, so the adhesive tapes attach properly.
4. The ProClip is in place.