

Manual, Assembly instruction: Brodit 853585

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap openers into the gap in the dashboard side wall, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the curved edge on the left part of the ProClip into the gap between the control panel and the dashboard. Press the right part of the ProClip forwards, so the curved left edge hooks behind the control panel.
3. Press the right part of the ProClip into the gap between the gap openers. Pull out the gap openers.
4. The ProClip is in place.