

Manual, Assembly instruction: Brodit 853588

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of the enclosed gap openers into the gap between the air vent frame and the dashboard, to widen the gap. Place the gap openers about 10 cm apart. Peel off the adhesive tape covers on the ProClip.
2. Press the vertical grooved edge on the ProClip into the gap between the gap openers. Begin with the upper corner.
3. Press firmly forward on the lower side of the ProClip so the rest of the grooved edge goes into the gap. Pull out the gap openers.
4. The ProClip is in place.