

Manual, Assembly instruction: Brodit 853589

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the surface where the ProClip is to be installed. Press the thin ends of the enclosed gap openers into the gap between the control panel and the dashboard, to widen the gap. Place the gap openers about 10 cm apart. Peel off the adhesive tape covers on the ProClip.
2. Press the ProClip into the gap between the gap openers.
3. Press forwards on the left part of the ProClip so the adhesive tape attaches to the control panel. Pull out the gap openers.
4. The ProClip is in place.