

Manual, Assembly instruction: Brodit 853590

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of the enclosed gap openers into the gap between the frame surrounding the air vent and the dashboard one above and one below the air vent, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. Press the lower part of the ProClip into the gap next to the gap opener.
2. Press forwards on the ProClip so the angled upper edge hooks into the gap next to the gap opener. Pull out the gap openers.
3. Press downwards on top of the ProClip so the angled edge goes all the way in the gap and the adhesive tape attaches.
4. The ProClip is in place.