

Manual, Assembly instruction: Brodit 853593

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap between the air vent and the surrounding frame.

2. Press downwards on the ProClip so the curved upper part hooks behind the air vent frame.

3. Press the lower part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

4. The ProClip is in place.