

Manual, Assembly instruction: Brodit 853610

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. To widen the gap, press the thin ends of the enclosed gap openers into the gap between the control panel and the surrounding dashboard, as shown in the picture. Peel off the adhesive tape covers on the ProClip.

2. Press the part with the adhesive tape into the gap above the gap opener.

3. Press the grooved edge of the ProClip into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap openers.

4. The ProClip is in place.