

Manual, Assembly instruction: Brodit 853613

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Hook the angled edge of the upper part of the ProClip into the gap between the frame surrounding the control panel and the dashboard.
2. Pull the ProClip towards you.
3. Hook the angled edge on the lower part of the ProClip into the upper edge of the air vent housing.
4. The ProClip is in place.