

Manual, Assembly instruction: Brodit 853615

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place the ProClip in the exact position as shown in the pictures.

1. Press the thin end of the enclosed gap openers into the gap between the center console panel frame and the air vent panel frame, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the grooved edge on the lower part of the ProClip into the gap between the gap openers. Press until you see or hear/feel it snaps into place. Pull out the gap openers.

3. Press a gap opener into the gap between the air vent panel frame and the dashboard (next to the ProClip). Press firmly forward on the upper part of the ProClip so the grooved edge goes into the next above the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.