

Manual, Assembly instruction: Brodit 853618

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to position the ProClip exactly as shown in the pictures. This ProClip consists of two parts. Part 1. Attaching part (the smallest part) Part 2. ProClip face plate

1. Press the thin ends of the enclosed gap openers into the gap in the center console sidewall as shown in the picture, to widen the gap. Peel off the adhesive tape cover on part 1. Press the edge on Part 1 into the gap next to the gap opener.

2. Press Part 1 upwards so the angled edge hooks behind the lower console sidewall and the adhesive tape attaches. Pull out the gap openers.

3. Open up the predrilled holes in Part 2 with a screwdriver (Philips). Peel off the adhesive tape covers on Part 2. Place Part 2 onto Part 1 so the holes match. Screw Part 2 onto Part 1 using the enclosed screws.

4. The ProClip is in place.