

Manual, Assembly instruction: Brodit 853620

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard ledge, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.

2. Press the lower part of the ProClip forwards, in the same time flip the ProClip upwards/forwards so the curved lower edge hooks behind the ledge. Pull out the gap opener.

3. Press downwards on the upper part of the ProClip, in the same time press forwards so the angled upper edge hook inside the upper edge of the air vent. Press upwards on the upper part of the ProClip so the angled edge hooks properly in place.

4. The ProClip is in place.