

## Manual, Assembly instruction: Brodit 853621

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. 1. Press the thin end of the enclosed Gap Opener (Spaltöffner) into the gap between the stereo and the surrounding frame, to widen the gap. Peel off the cover of the adhesive tape on the ProClip. 2. Press the left part of the ProClip, with adhesive tape, into the gap below the Gap Opener (Spaltöffner). 3. Press forwards on the right side of the ProClip so the angled right edge hooks into the gap between the frame surrounding the control panel and the dashboard. Press until you hear + feel it snaps into place. Pull out the Gap Opener (Spaltöffner). 4. The ProClip is in place.