

Manual, Assembly instruction: Brodit 853624

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hook/press the curved edge on the lower part of the ProClip into the gap between the center console panel frame and the wood grain panel.
2. Press firmly forward on the upper part of the ProClip so the grooved edge goes into the gap between the air vent and the dashboard overhang.
3. Press until you see or hear/feel it snaps into place.
4. The ProClip is in place.