

Manual, Assembly instruction: Brodit 853626

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thick end of the enclosed gap opener into the gap between the air vent panel frame and the padded dashboard, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the angled edge on the lower part of the ProClip underneath the air vent panel frame.

3. Press firmly forward on the upper part of the ProClip so the grooved edge goes into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

4. The ProClip is in place.