

Manual, Assembly instruction: Brodit 853628

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Place the ProClip over the console edge and press the left side of the ProClip towards the console edge so the adhesive attaches properly.

2. Press firmly forward on the right side of the ProClip so the angled edge snaps over the console edge in the sidewall.

3. The ProClip is in place.

4. The ProClip is in place.