

Manual, Assembly instruction: Brodit 853639

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the two panel frames, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Place/press the angled edge on the lower part of the ProClip into the gap next to the gap opener.

3. Flip the ProClip forward, towards the air vent. Press firmly down on top of the ProClip and hook the thin end with adhesive tape into the air vent. Pull out the gap opener.

4. The ProClip is in place.