

Manual, Assembly instruction: Brodit 853640

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap sidewall, to widen the gap. Peel off the cover of adhesive tape on the ProClip.
2. Press the angled edge on the left side of the ProClip into the gap between the stereo and the console edge.
3. Press firmly forward on the right side of the ProClip so angled edge goes into the gap above the gap opener. Press on the side with your finger to make sure the angled edge is all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.