

Manual, Assembly instruction: Brodit 853643

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the angled edge on the left side of the ProClip into the gap between the console edge and the center console panel frame.
2. Press firmly forward on the right side of the ProClip so angled edge goes into the gap between the console sidewall and the padded part of the dashboard. Press until you see or hear/feel it snaps into place.
3. Press firmly forward on the left side of the ProClip for best possible attachment of the adhesive tape.
4. The ProClip is in place.