

Manual, Assembly instruction: Brodit 853644

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the two panel frames, to widen the gap. Peel off the cover of adhesive tape on the ProClip.

2. Press the grooved edge on the lower part of the ProClip into the gap next to the gap opener. Press until you see or hear/feel it snaps into place. Pull out the gap opener.

3. Flip the ProClip forward, towards the air vent. Lift the upper part upwards and press firmly forward on top of the ProClip so the angled edge goes into the gap between the wood grain panel and the padded part of the dashboard.

4. The ProClip is in place.