

Manual, Assembly instruction: Brodit 853650

Angled mount, High ONLY for wood grain panel.



Please read all of the instructions and look at the pictures before attaching the ProClip. The pictures show an installation in a vehicle without wood grain panel, the same instructions apply also for vehicles with wood grain panel.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard, to widen the gap.
2. Press the grooved edge on the upper part of the ProClip into the gap next to the gap opener. Press until you hear/feel it snaps into place. Pull out the gap opener.
3. Press the gap opener into the gap between the frame surrounding the control panel and the dashboard. Press forwards on the lower part of the ProClip so the grooved edge snaps into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.