

Manual, Assembly instruction: Brodit 853651

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the coin shelf and the surrounding frame, to widen the gap. Peel off the adhesive tape covers on the ProClip. Hook the right end of the ProClip into the gap between the frame surrounding the control panel and the dashboard.
2. Pull the ProClip leftwards. Hook the left end of the ProClip into the gap above the gap opener.
3. Press forwards on the left side of the ProClip so it goes all the way into the gap. Pull out the gap opener.
4. The ProClip is in place.