

Manual, Assembly instruction: Brodit 853652

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Peel off both adhesive tape covers on the ProClip.
2. Press the angled edge on the left end of the ProClip into the gap above the gap opener. Pull out the gap opener.
3. Press the long right end of the ProClip into the gap between the dashboard surrounding the glove compartment and the center console side wall.
4. The ProClip is in place.