

Manual, Assembly instruction: Brodit 853653

Angled mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the center console sidewall, to widen the gap.
2. Press the angled left edge of the ProClip into the gap between the stereo and the surrounding frame.
3. Press forwards on the right side of the ProClip so the angled right edge snaps into place in the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.