

Manual, Assembly instruction: Brodit 853655

Angled mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of the enclosed gap openers into the gap in the dashboard. Place them about 10 cm apart. Peel off the adhesive tape cover on the ProClip.
2. Press the curved edge on the upper part of the ProClip into the gap between the gap openers. Flip the lower part of the ProClip downwards so the upper curved edge hooks into the gap. Pull out the gap openers.
3. Hook the lower part of the ProClip, with adhesive tape, under the edge of the dashboard.
4. The ProClip is in place.