

Manual, Assembly instruction: Brodit 853658

Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the air vent frame and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the angled edge on the lower part of the ProClip into the gap below the dashboard ledge.
3. Press forwards on the upper part of the ProClip so the angled edge hooks into the gap next to the gap opener. Pull out the gap opener.
4. The ProClip is in place.