

Manual, Assembly instruction: Brodit 853660

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.
2. Flip the ProClip upwards so the lower angled edge hooks behind the air vent frame.
3. Press the upper part of the ProClip into the gap in the dashboard.
4. The ProClip is in place.